

SPECIFICATIONS

Item No.: ACA2200

Description: High Accuracy Digital Type Dual-Axis Inclinometer

with Full Temperature Compensation

Production implementation standard reference

- Enterprise quality system standards: ISO9001: 2008 standard (certification number: 128101)
- Tilt sensor production standards: GB / T 191 SJ 20873-2003 inclinometer general specification of Level
- •The Academy of metrology and quality inspection Calibrated in accordance to: JJF1119-2004 Electronic Level calibration Specification
- Gyro accelerometer test standard: QJ 2318-92 Gyro accelerometer test methods
- Software development reference standard: GJB 2786A-2009 military software development General requirements
- Product environmental testing standards: GJB150
- Electromagnetic anti-interference test standards: GB / T 17626
- Version: Ver.09
- Date:2014.3.11





General Description

ACA2200 is a analog balanced servo inclinometer which manufactured by Rion company, the principle is composed of the non-contact displacement sensor, torque motor, error & amplifier circuit, the feedback circuit and cantilever mass five parts. This series inclinometer accuracy is far superior than the inclinometer relative to the electrolyte principle or the capacitance principle on the nonlinearity,repeatability, hysteresis, temperature drift and working temperature, resistance shock anti-vibration and other properties.Internal integration of the 24 ARM high-end system,resolution 0.0001°, precision 0.001°, temperature drift: 0.0008° C /°, response frequencies up to 300Hz (baud rate 115200),it is a highly competitive industry product nowadays .Non-contact installation features make ACA2200 with superior system integration, Simply fix the sensor on the measured surface by screws , then can automatically calculate the object posture inclination, easy to use , no need to find the relative change two surfaces for mounting . With strong ability resistance to external electromagnetic interference and to withstand shock and vibration,in the domestic counterparts products with absolute competitive advantage, specialized in application in the industrial and military fields where the high-end user requirements.

Features

•Dual-Axis Inclinometer

Application:

- •Response frequence: 300Hz
- •Wide temperature working: -40~+85℃
- Size:110×65×40mm(customized)
- ●Output mode RS232、RS485、TTL、PWM are optional

d ●Water-proof air-plug

- •Engineering vehicles automatic leveling
- •Precise equipment level control
- •Underground drill posture navigation
- •Based on the angle direction measurement
- •Bridge & dam detection
- Medical facilities angle control
- Railway gauging rule , gauge equipment leveling

Measuring Range :±1~±90° optional


Wide voltage input: 9~36V

• Resolution: 0.0001°


•IP67 protection class

- Geological equipment inclined monitoring
- •Directional satellite communications antenna pitching angle measurement





Ordering information:



E.g: ACA2200-05-232: Dual-axis/±5°Measuring range/RS232 output

Technical Data

| Parameters Cor | nditions | | | | Unit |
|------------------|--|---------|---------|---------|--------------|
| Measuring | | ±05 | ±10 | ±15 | ۰ |
| range | | | | | |
| Measuring axis | | X, Y | XY | XY | |
| Resoluition | | 0.0001 | 0.0001 | 0.0001 | ۰ |
| Absolute | | 0.003 | 0.005 | 0.006 | • |
| accuracy | | | | | |
| Long term | | 0.002 | 0.003 | 0.005 | |
| stability | | | | | |
| Zero | -40~85° | ±0.0008 | ±0.0008 | ±0.0008 | %℃ |
| temperature | | | | | |
| coefficient | | | | | |
| Sensitivity | -40~85° | ≤50 | ≤50 | ≤50 | ppm/ |
| temperature | | | | | $^{\circ}$ C |
| coefficient | | | | | |
| Power on time | | 0.3 | 0.3 | 0.3 | S |
| Response time | | 0.005 | 0.005 | 0.005 | S |
| Output rate | 5Hz、15Hz、35Hz、50Hz、100Hz、300Hz can be set | | | | |
| Out signal | RS232/RS485/RS422/TTL/CAN | | | | |
| Electromagnetic | According to EN61000 and GBT17626 | | | | |
| compatibility | | | | | |
| MTBF | ≥50000hours / times | | | | |
| Insulation | ≥100M | | | | |
| Resistance | | | | | |
| Shockproof | 100g@11ms、imes/Axis(half sinusoid) | | | | |
| Anti-vibration | 10grms、10~1000Hz | | | | |
| Protection glass | IP67 | | | | |
| Cables | Standard 1M length、wearproof、wide temperature、 | | | | |
| | Shielded cables4*0.4mm2 air-plug connector | | | | |
| Weight | 150g(without cable) | | | | |

Electronic Characteristics

| Parameters | Conditions | Min | Standard | Max | Unit |
|---------------------|------------|-----|---------------|------|--------------|
| Power supply | Standard | 9 | 24 | 36 | V |
| | customized | | Other voltage | | V |
| Working current | No-load | | 50 | | mA |
| Working temperature | | -40 | | +85 | $^{\circ}$ C |
| Store temperature | | -55 | | +100 | $^{\circ}$ |

Key words:

Resolution: Refers to the sensor in measuring range to detect and identify the smallest changed value.

Absolute accuracy: Refers to in the normal temperature circumstances, the sensor absolute linearity,

repeatability, hysteresis, zero deviation, and transverse error comprehensive error.

Long term stability: Refers to the sensors in normal temperature conditions, the deviation between the

maximum and minimum values after a year's long time work.

Response time: Refers to the sensor in an angle change, the sensor output value reached the standard

time required.

Mechanical Parameters


o Connectors: 1m cable with air-plug connector (customized)

Protection glass: IP67(air plug connector)
Enclosure material: Aluminum Shield Oxide

o Installation: 4*M5 screws

Measuring Directions&Fix


The installation must guarantee the product bottom is parallel to measured face, and reduce the influence of dynamic and acceleration to the sensor. This product can be installed horizontally or mounted vertically (mounted vertically selection is only applicable to the single axis), for installation please refer to the following scheme.



Production installation notes:


Please follow the correct way to install tilt sensor, incorrect installation can cause measurement errors, with particular attention to the "surface", "line":: 1) The Sensor mounting surface and the measured surface must be fixed closely, smoothly, stability, if mounting surface uneven likely to cause the sensor to measure the angle error. See Figure Pic.AB

2) The sensor axis and the measured axis must be parallel ,the two axes do not produce the angle as much as possible. See Figure Pic.CD




Electrical Connection

| Line | BLACK | WHITE | BLUE | BROWN | GRAY |
|---------|------------------|--------------|--------------|-----------------------|----------|
| color | GND | RS232(RXD) | RS232(TXD) | Vcc 9∼36V | FACTORY |
| functio | n Power Negative | Or RS485(D+) | Or RS485(D-) | Power supply positive | Use only |




Dimension



Size:110×65×40mm(customized)

RION serial port tester software

You can download the RION angle debugging software from RION's official website for the preliminary angle debugging, also you Can download public version of the serial port assistant software on line for using .



Open/Close: Open and close COM port;


Com: Select the the device corresponding to the COM port

Address: Fill in the sensor current address code, the factory default is 00

Set Address: Set the sensor address code input box on the right to enter the desired address code, click Set Addr button

Save Data: Save the data, click here data can be synchronized Save angle data, the file is stored by default in the C: ---- COMDATA file





Set Zero: Set relative zero, the sensor current angle is 00.00 degrees

Cancel Zero: Unset the relative zero, to restore the sensor to the factory absolute zero;

Baud Rate: Select the sense baud rate, the factory default is 9600;

Set Baud Rate: Set the sensor baud rate, on the right of the selection box to select corresponding baud rate then click SetB.R. button;

Auto Output: Switch the sensor to automatically output mode, in the automatic output mode can be filled with different output frequency in Hz;

Catechism: The sensor switch to answer pattern, such as choosing the answer type, must input "send command "(command, please refer to the specification) on the left of "Send Command" input box, but also can fill in the transmit frequency in the Send Data, the unit Hz;

Note: after install the RION's debugging software, if can not open, please operate by the following steps (please appear to the administrator status to operate):

- 1) Copy these three files mscomm.srg、mscomm32.ocx、mscomm32.dep from the folder to C:/Windows/system32 path below。
- 2) Click "Start" "run" -- regsvr32 mscomm32.ocx, You are prompted to install successful dialog.

Product Protocol

1.DATA FRAME FORMAT:

(8 bits date, 1 bit stop, No check, Default baud rate 9600)

| Identifier | Date Length | Address code | Command word | Date domain | Check sum |
|------------|-------------|--------------|--------------|-------------|-----------|
| (1byte) | (1byte) | (1byte) | (1byte) | | (1byte) |
| 68 | | | | | |

Date format: hexadecimal

Identifier: Fixed68

Data length: From data length to check sum (including check sum) length

Address code: Accumulating module address, Default:00


Date domain will be changed according to the content and length of command word

Check sum: Data length, Address code, Command word and data domain sum, No carry.

L. COMMAND word analysis

| Desc. | Meaning/Example | Description |
|-------|--|---|
| 0x01 | read X axis angle command eg: 68 04 00 01 05 | data field(0 byte) no data field command |
| 0x81 | sensor responds eg: 68 07 00 81 10 26 87 60 A5 | data field(4 byte) SS AA BB BB, data field is 4 bytes responding angle value(BCD compressed code), SS is sign bit(00 is positive, 10 is negative), AA is two digit integer value, BBBB is three digit decimal. other axis data is the same. eg: 10268760 indicates -26.8760 deg |
| 0x02 | responding command read Y axis angle | data field(0 byte) no data field command |
| 0x82 | sensor responds | "data field(4 byte) SS AA BB BB, data field is |

| | eg 68 07 00 82 00 16 25 05 | 4 bytes responding angle value(BCD |
|------|--|--|
| | C9" | compressed code), SS is sign bit(00 is |
| | | positive, 10 is negative), AA is two digit |
| | | integer value, BBBB is three digit decimal. |
| | | other axis data is the same. |
| | | eg: 00162505 indicates +16.2505 deg |
| | | 3 |
| 0X04 | Meanwhile read angle command | Data domain(0byte) |
| | E.g: 68 04 00 04 08 | No Data domain command |
| 0X84 | sensor data response | data field(9byte) |
| | Eg: | 68 is prefix of data packets, fixed. |
| | 68 0D 00 84 00 20 10 10 40 | 0D is data lenght, fixed. |
| | 00 05 05 00 3B | 00 is address code, revisable. |
| | | 84 is command code, fixed. |
| | | 00 20 10 the three red bytes are the X axis |
| | | returned angle value in compact BCD code. |
| | | the high order 0 of first byte is sign bit(0: |
| | | positive; 1: negative), 02 are two digit integer |
| | | value, 010 are three decimal digit. other |
| | | axis data analysis method is similar. |
| | | the angle is +02.010deg by analizing. |
| | | 10 40 00, the three blue bytes are Y axis |
| | | returned angle value, analysis method is |
| | | similar to X axis |
| | | 05 05 00, the three green bytes are internal |
| | | temperature value, analysis method is similar |
| | | to X axis. |
| | | 3B check sum, hexadecimal sum of all |
| | | data, exclude prefix 68, |
| | | if surpass one byte, pick |
| OVOE | Octobra valetiva/eh estute ZEDO. | low-order. |
| 0X05 | Setting relative/absolute ZERO: Can set the current angle to | Data domain (1byte) |
| | Zero degree, relative | 00: absolute ZERO |
| | measurement, can also be set to | 01: relative ZERO |
| | absolute ex-factory zero, power off | 01. Telative ZEINO |
| | save | |
| | Save | |
| | E.g: 68 05 00 05 00 0A | |
| 0X85 | Sensor answer reply command | Data domain (1byte) |
| | E.g: 68 05 00 85 00 8A | Data domain in the number means the sensor |
| | | response results |
| | | 00 Setting successfully |
| | | FF Setting failure |
| 0X0B | Setting communication rate | Data domain(1byte) |
| | E.g: <i>68 05 00 0B 03 13</i> | Baud rate: default :9600 |
| 1 | The command setting is effective | 00 means 2400 |
| | _ | 00 means 2400 |
| | after power off then restart | 01 means 4800 |




| | | 03 means 19200 | |
|------|----------------------------------|--|--|
| | | | |
| | | 04 means 38400 | |
| AVAD | | 05 means 115200 | |
| 0X8B | Sensor answer reply command | Data domain (1byte) | |
| | E.G:68 05 00 8B 90 | Data domain in the number means the sensor | |
| | | response results | |
| | | 00 Success FF Failure | |
| OXOC | Setting sensor output mode | Data domain | |
| | Response rule; | (1byte) Factory default: 00 | |
| | Need upper computer send | 00 Answer reply mode | |
| | reading angle command , the | 01 5Hz Automatical output mode | |
| | sensor answer | 02 15Hz Automatical output mode | |
| | the corresponding angle | 03 25Hz Automatical output mode | |
| | Automatic output rule: | 04 35Hz Automatical output mode | |
| | The sensor with power on can | 05 50Hz Automatical output mode | |
| | Automatically output X angle , | 06 100 Hz Automatical output mode | |
| | output frequency is 20HZ | 07 200Hz Automatical output mode | |
| | (Power off with save function) | 08 300Hz Automatical output mode | |
| | E.g: 68 05 00 0C 00 11 | | |
| OX8C | The sensor answer reply | Data domain (1byte) | |
| | command | Data domain in the number means the sensor | |
| | E.g: 68 05 00 8C 00 91 | response results | |
| | | 00 Success FF Failure | |
| | Setting the address to 01 | | |
| | 68 05 FF 0F 00 13 | | |
| | Use the common address reset | | |
| | address to 00 | | |
| 0X8F | The sensor answer reply | Data domain (1byte) , | |
| | E.g: 68 05 00 8F 94 | Data domain in the number means the sensor | |
| | | response results | |
| | | Success FF Failure | |
| OXOD | Check relative/absolute ZERO | Data domain(0 byte) | |
| | Used to check the current ZERO | 00 No data domain | |
| | mode of the sensor is relative | | |
| | zero or absolute zero | | |
| | Eg.: 68 04 00 0D 11 | | |
| OXOD | Query relative/absolute ZERO | Data domain (0byte) | |
| | Used to query the sensor current | No data domain commands | |
| | ZERO mode is relative ZERO | | |
| | or absolute ZERO | | |
| | E.g : 68 04 00 0D 11 | | |
| 0X8D | The sensor answer reply | Data domain (1byte), | |
| | | Data domain in the number means the sensor | |
| | command | Data domain in the number means the sensor | |
| | | response results | |
| | E.g: 68 05 00 8D 00 92 | | |



*More products information, please refer to the company's Website : www.rion-tech.net







深圳市瑞分科技有限公司

CHINA SHENZHEN RION TECHNOLOGY CO.,LTD.

✓ 倾角传感器 ✓ 倾角(调平)开关 ✓ 数显水平仪 ✓ 陀螺仪✓ 三维电子罗盘 ✓ 加速度计 ✓ 航姿参考系统 ✓ 寻北仪

T: 0755-29657137/29761269 F: 0755-29123494 W: www.rion-tech.net E: sales@rion-tech.net A: 中国・深圳市宝安82区华丰科技园五期3F